

## **[travelvolts.net](http://travelvolts.net) pump/tap wiring kit.**

Connect one wire from the tap to one wire from the pump together using one of the supplied connectors.

Connect one end of the green wire to the remaining tap wire. Connect one end of the brown/red wire to the remaining pump wire.

Use the other two supplied connectors to do this.

If using a wall switch for the pump circuit run the green wire from the tap to the wall switch. Connect the green wire to one terminal of the switch. Connect the other switch terminal to the battery + or fuse box using the rest of the green wire . Place the fuse about 200 mm from the battery terminal if not using a fuse box.

Connect the other end of the brown/red wire from the pump to the battery negative or a suitable earth point on the vehicle body.

For info on how to use these connectors view the You tube video here

<http://www.rapidonline.com/Cables-Connectors/Jowtek-IDC-Connectors-Packs-of-10-550287>



**[travelvolts.com](http://travelvolts.com)**

For assistance phone 07971 165747

travelvolts accepts no liability for injury or damage caused by the incorrect fitment or use of this product.